

\$40	( read_n / write )	ID ID	\$08 \$D4	MSX2+ FS-A1 Series MSX++ 1chipMSX, Zemmix Neo, etc.	Z80B 5.37MHz OCM-PLD v2.4 or later
\$41	( read_n / write )	BIT 0		Smart Command ID	CPL or \$FF (Null)
		BIT 1			
		BIT 2			
		BIT 3			
		BIT 4			
		BIT 5			
		BIT 6			
\$42	( read / write_n )	BIT 7			
		BIT 0	CPU Clock	Virtual DIP-SW1	
		BIT 1	Video Output (MSB)	Virtual DIP-SW2	
		BIT 2	Video Output (LSB)	Virtual DIP-SW3	
		BIT 3	Cartridge Slot-1	Virtual DIP-SW4	
		BIT 4	Cartridge Slot-2 (MSB)	Virtual DIP-SW5	
		BIT 5	Cartridge Slot-2 (LSB)	Virtual DIP-SW6	
\$43	( read / write_n )	BIT 6	Current Mapper Size	Virtual DIP-SW7	
		BIT 7	Current MegaSD Mode	Virtual DIP-SW8	
		BIT 0		CPU Clock	
		BIT 1		Video Output	
		BIT 2		Audio Mixer & SCRLK	
		BIT 3	Lock Mask of the Toggles	Cartridge Slot-1	
		BIT 4		Cartridge Slot-2	
BIT 5	Hard Reset Key				
BIT 6	Internal Mapper				
\$44	( read / write_n )	BIT 7		Internal MegaSD	
		BIT 0		Led 1 Status	
		BIT 1		Led 2 Status	
		BIT 2		Led 3 Status	
		BIT 3	Lights I/O	Led 4 Status	
		BIT 4	(SM-X and SX-2 only use Led 8 but this register works the same way)	Led 5 Status	
		BIT 5		Led 6 Status	
BIT 6	Led 7 Status				
BIT 7	Led 8 Status				
\$45	( read / write_n )	BIT 0		BIT 0 (LSB)	
		BIT 1	PSG Volume Level	BIT 1	
		BIT 2		BIT 2 (MSB)	
	( read only )	BIT 3	PSG Mute	Status	
		BIT 4		BIT 0 (LSB)	
	( read / write_n )	BIT 5	Master Volume Level	BIT 1	
		BIT 6		BIT 2 (MSB)	
( read only )	BIT 7	Master Mute	Status		
\$46	( read / write_n )	BIT 0		BIT 0 (LSB)	
		BIT 1	OPLL Volume Level	BIT 1	
		BIT 2		BIT 2 (MSB)	
	( read only )	BIT 3	OPLL Mute	Status	
		BIT 4		BIT 0 (LSB)	
	( read / write_n )	BIT 5	SCC-I Volume Level	BIT 1	
		BIT 6		BIT 2 (MSB)	
( read only )	BIT 7	SCC-I Mute	Status		
\$47	( read only )	BIT 0		BIT 0 (LSB)	
		BIT 1	CPU Custom Speed Level	BIT 1	
		BIT 2		BIT 2 (MSB)	
		BIT 3	Turbo MegaSD (tMSD)	Status	
		BIT 4	Turbo Pana Redirection (tPR)	Status	
		BIT 5	VDP Speed Mode	0=Normal, 1=Fast	
		BIT 6	Mapper Size Req	0=2048kB, 1=4096kB	
BIT 7	MegaSD Mode Req	Status			
\$48	( read only )	BIT 0		Turbo Pana	Status
		BIT 1	Current Keyboard Layout	0=JP, 1=Non-JP	
		BIT 2	SCRLK Toggle	Status	
		BIT 3	Lights Mode	0=Auto, 1=ON	
		BIT 4	Red Mode (Led 0)	Status	
		BIT 5	Last Reset Flag	0=Cold, 1=Warm	
		BIT 6	Reset Required Flag	Status	
BIT 7	MegaSD Blink	Status			
\$49	( read only )	BIT 0	Pseudo Stereo	Status	
		BIT 1	External Clock Mode	0=Sync to CPU, 1=3.58Mhz	
		BIT 2	Machine Type ID	BIT 0 (LSB)	
		BIT 3	(0=1chipMSX, 1=Zemmix Neo/SX-1 and related, 2=SM-X/MC2P, 3=SX-2, 4=SM-X Mini/SMX-HB, 5=DE0CV, 6-14=Free, 15=Unknown)	BIT 1	
		BIT 4		BIT 2	
		BIT 5		BIT 3 (MSB)	
		BIT 6		0=Forced, 1=Auto	
BIT 7	NTSC/PAL Type	0=60Hz (NTSC), 1=50Hz (PAL)			
\$4A	( read only )	BIT 0	Forced Video Mode	Status	
		BIT 1	Right Inverse Audio	Status	
		BIT 2	Pixel Ratio 1:1 for LED Display	BIT 0 (LSB)	
		BIT 3		BIT 2 (MSB)	
		BIT 4	Centering YJK Modes/R25 Mask	Status	
		BIT 5	Assignment of Legacy Output	0=To VGA, 1=To VGA+	
		BIT 6	Internal Slot-1 Linear	Status	
BIT 7	Internal Slot-2 Linear	Status			
\$4B	( read only )	BIT 0		BIT 0 (LSB)	only for SM-X / SX-2
		BIT 1	VGA Scanlines Level (ID*25%)	BIT 1 (MSB)	only for SM-X / SX-2
		BIT 2	Internal PSG2	Status	only for SM-X / SX-2
		BIT 3	SDRAM Size	BIT 0 (LSB)	
		BIT 4	(0=8MB, 1=16MB, 2=32MB, 3=reserved)	BIT 1 (MSB)	
		BIT 5	OCM-BIOS Reloading Req	Status	
		BIT 6	Extra-Mapper 4096kB Req	Status	
BIT 7	Slot-0 Mode Req	0=Primary, 1=Expanded			
\$4B	( read only )	BIT 0		BIT 0 (LSB)	
		BIT 1		BIT 1	
		BIT 2		BIT 2	
		BIT 3	Free	BIT 3	
		BIT 4		BIT 4	
		BIT 5		BIT 5	
		BIT 6		BIT 6	
BIT 7		BIT 7 (MSB)			
\$4C	( read only )	BIT 0		CPU Clock	Hard DIP-SW1
		BIT 1	Video Output (MSB)	Hard DIP-SW2	
		BIT 2	Video Output (LSB)	Hard DIP-SW3	
		BIT 3	Cartridge Slot-1	Hard DIP-SW4	
		BIT 4	Cartridge Slot-2 (MSB)	Hard DIP-SW5	
		BIT 5	Cartridge Slot-2 (LSB)	Hard DIP-SW6	
		BIT 6	Internal Mapper	Hard DIP-SW7	
BIT 7	Internal MegaSD	Hard DIP-SW8			
\$4D	( read / write_n )	BIT 0		BIT 0 (LSB)	
		BIT 1		BIT 1	
		BIT 2	64kB VRAM Slot ID (Page 0)	BIT 2	
		BIT 3		BIT 3 (MSB)	
		BIT 4		BIT 0 (LSB)	
		BIT 5	64kB VRAM Slot ID (Page 1)	BIT 1	
		BIT 6		BIT 2	
BIT 7	BIT 3 (MSB)				
\$4E	( read only )	BIT 0		BIT 0 (LSB)	
		BIT 1		BIT 1	
		BIT 2		BIT 2	
		BIT 3	OCM-PLD main version X.Y{.Z} (range 0.0.z - 25.5.z)	BIT 3	
		BIT 4		BIT 4	
		BIT 5		BIT 5	
		BIT 6		BIT 6	
BIT 7		BIT 7 (MSB)			
\$4F	( read only )	BIT 0		BIT 0 (LSB)	
		BIT 1	I/O Revision ID (0 - 31)	BIT 1	
		BIT 2		BIT 2	
		BIT 3		BIT 3	
		BIT 4		BIT 4 (MSB)	
		BIT 5	OCM-PLD sub version (x.y).Z (range x.y.0 - x.y.3)	BIT 0 (LSB)	
		BIT 6		BIT 1 (MSB)	
BIT 7	Default Keyboard Layout	Status			
Reserved to IPL-ROM					
\$4C	( write_n only )	BIT 0 - 7		VDP ID Selector	0-1=ID0 (V9938), 2-255=ID2 (V9958)
\$4E	( write_n only )	BIT 0 - 6		-	-
\$4F	( write_n only )	BIT 7		JIS2 Enabler	0=JIS1+JIS2, 1=JIS1 only
		BIT 0 - 6		-	-
\$4F	( write_n only )	BIT 7		F4 Device Mode	0=Normal, 1=Inverted

SMART COMMANDS TABLE					
\$00	( 000 )			Null Command (reserved)	
\$01	( 001 )			Set Turbo Pana Redirection OFF (default)	
\$02	( 002 )			Set Turbo Pana Redirection ON	
\$03	( 003 )			Set Standard Speed 3.58MHz	
\$04	( 004 )			Set Custom Speed 4.10MHz	
\$05	( 005 )			Set Custom Speed 4.48MHz	
\$06	( 006 )			Set Custom Speed 4.90MHz	
\$07	( 007 )			Set Custom Speed 5.39MHz	
\$08	( 008 )			Set Custom Speed 6.10MHz	
\$09	( 009 )			Set Custom Speed 6.96MHz	
\$0A	( 010 )			Set Custom Speed 8.06MHz (aka "Turbo 10MHz") (default)	
\$0B	( 011 )			Set Turbo MegaSD OFF	
\$0C	( 012 )			Set Turbo MegaSD ON (default)	
\$0D	( 013 )			Set External Slot-1 + External Slot-2	
\$0E	( 014 )			Set Internal SCC-I Slot-1 + External Slot-2	
\$0F	( 015 )			Set External Slot-1 + Internal SCC-I Slot-2	
\$10	( 016 )			Set Internal SCC-I Slot-1 + Internal SCC-I Slot-2	
\$11	( 017 )			Set External Slot-1 + Internal ASCII-8K Slot-2	
\$12	( 018 )			Set Internal SCC-I Slot-1 + Internal ASCII-8K Slot-2	
\$13	( 019 )			Set External Slot-1 + Internal ASCII-16K Slot-2	
\$14	( 020 )			Set Internal SCC-I Slot-1 + Internal ASCII-16K Slot-2	
\$15	( 021 )			Set Japanese Keyboard Layout	
\$16	( 022 )			Set Non-Japanese Keyboard Layout	
\$17	( 023 )			Set Display Mode 15KHz Composite/S-Video	
\$18	( 024 )			Set Display Mode 15KHz RGB w/ Audio Out	
\$19	( 025 )			Set Display Mode 31KHz VGA for LED TV or LED Display	also HDMI AV on SM-X
\$1A	( 026 )			Set Display Mode 31KHz VGA+ for CRT Monitor (legacy output)	also HDMI AV on SM-X
\$1B	( 027 )			Set VDP Speed Normal Mode (default)	
\$1C	( 028 )			Set VDP Speed Fast Mode (V9958 only)	
\$1D	( 029 )			Reserve MegaSD OFF (warm reset to go)	
\$1E	( 030 )			Reserve MegaSD ON (warm reset to go)	
\$1F	( 031 )			Set MegaSD Blink OFF	
\$20	( 032 )			Set MegaSD Blink ON (default)	
\$21	( 033 )			Set Lights Mode OFF w/ Auto LEDs Control (default)	
\$22	( 034 )			Set Lights Mode ON + Red Led OFF	
\$23	( 035 )			Set Lights Mode ON + Red Led ON	
\$24	( 036 )			Internal Audio Preset #1 "Mute Sound"	
\$25	( 037 )			Internal Audio Preset #2 "Middle Sound"	
\$26	( 038 )			Internal Audio Preset #3 "High Sound" (default)	
\$27	( 039 )			Set CMT OFF (default) [disabled w/ MSXtr BIOS]	n/a on SM-X / SX-2
\$28	( 040 )			Set CMT ON (needs a cassette recorder) [disabled w/ MSXtr BIOS]	n/a on SM-X / SX-2
\$29	( 041 )			Lock Turbo Toggles	
\$2A	( 042 )			Unlock Turbo Toggles	
\$2B	( 043 )			Lock Display Toggles	
\$2C	( 044 )			Unlock Display Toggles	
\$2D	( 045 )			Lock Audio Mixer & SCRLK Toggles	
\$2E	( 046 )			Unlock Audio Mixer & SCRLK Toggles	
\$2F	( 047 )			Lock Slot-1 Toggles	
\$30	( 048 )			Unlock Slot-1 Toggles	
\$31	( 049 )			Lock Slot-2 Toggles	
\$32	( 050 )			Unlock Slot-2 Toggles	
\$33	( 051 )			Lock Slot-1 & Slot-2 Toggles	
\$34	( 052 )			Unlock Slot-1 & Slot-2 Toggles	
\$35	( 053 )			Lock Hard Reset Key	
\$36	( 054 )			Unlock Hard Reset Key	
\$37	( 055 )			Lock Mapper Toggle	
\$38	( 056 )			Unlock Mapper Toggle	
\$39	( 057 )			Lock MegaSD Toggle	
\$3A	( 058 )			Unlock MegaSD Toggle	
\$3B	( 059 )			Lock All Toggles	
\$3C	( 060 )			Unlock All Toggles (default)	
\$3D	( 061 )			Set Pseudo-Stereo OFF (default)	
\$3E	( 062 )			Set Pseudo-Stereo ON (needs an external sound cartridge)	
\$3F	( 063 )			Sync External Bus Clock to CPU Speed (default)	
\$40	( 064 )			Set External Bus Clock 3.58MHz	
\$41	( 065 )			Set Turbo Pana 5.37MHz	
\$42	( 066 )			Set Right Inverse Audio OFF (default)	
\$43	( 067 )			Set Right Inverse Audio ON	
\$44	( 068 )			Internal Audio Preset #4 "Emphasis PSG Sound"	
\$45	( 069 )			Internal Audio Preset #5 "Emphasis SCC-I Sound"	
\$46	( 070 )			Internal Audio Preset #6 "Emphasis OPLL Sound"	
\$47	( 071 )			Vertical Offset 16 (useful for Ark-A-Noah)	
\$48	( 072 )			Vertical Offset 17	
\$49	( 073 )			Vertical Offset 18	
\$4A	( 074 )			Vertical Offset 19 (default)	
\$4B	( 075 )			Vertical Offset 20	
\$4C	( 076 )			Vertical Offset 21	
\$4D	( 077 )			Vertical Offset 22	
\$4E	( 078 )			Vertical Offset 23	
\$4F	( 079 )			Vertical Offset 24 (useful for Space Manbow)	
\$50 .. \$53	( 080 .. 083 )			Set VGA Scanlines 0% .. 25% .. 50% .. 75% (default is 0%)	only for SM-X / SX-2
\$54	( 084 )			Internal PSG2 OFF (default)	only for SM-X / SX-2
\$55	( 085 )			Internal PSG2 ON (this second PSG acts as an external PSG)	only for SM-X / SX-2
\$56	( 086 )			Set Extra-Mapper 4096 kB OFF (default)	
\$57	( 087 )			Set Extra-Mapper 4096 kB ON (only available if SDRAM > 8MB)	
...	...			...	
\$7F	( 127 )			Pixel Ratio 1:1 for LED Display (default is 0) (range 0-7) (60Hz only)	
\$80	( 128 )			Null Command (useful for programming)	
\$81	( 129 )			Assign Legacy Output to VGA	
\$82	( 130 )			Assign Legacy Output to VGA+ (default)	
\$83	( 131 )			Set Internal Slot-1 Linear OFF (default)	
\$84	( 132 )			Set Internal Slot-1 Linear ON (requires SCC-I preset)	
\$85	( 133 )			Set Internal Slot-2 Linear OFF (default)	
\$86	( 134 )			Set Internal Slot-2 Linear ON (requires SCC-I or ASCII-8K/16K preset)	
\$87	( 135 )			Set Internal OPL3 OFF .. ON (default)	only for SM-X / SX-2
\$88	( 136 )			Set Internal OPL3 ON	only for SM-X / SX-2
\$89 .. \$8F	( 137 .. 143 )			Reserved (Ducaps)	only for SM-X / SX-2
...	...			...	
\$B0 .. \$B7	( 176 .. 183 )			Set Master Volume 0 .. 7 (default level is 7)	
\$B8 .. \$BF	( 184 .. 191 )			Set PSG Volume 0 .. 7 (default level is 4)	
\$C0 .. \$C7	( 192 .. 199 )			Set SCC-I Volume 0 .. 7 (default level is 4)	
\$C8 .. \$CF	( 200 .. 207 )			Set OPLL Volume 0 .. 7 (default level is 4)	
\$D0	( 208 )			Force NTSC Mode	
\$D1	( 209 )			Standard NTSC/PAL Mode (bound by Control Register 9) (default)	
\$D2	( 210 )			Force PAL Mode	
\$D3	( 211 )			Restore Default Keyboard Layout	
\$D4	( 212 )			Null Command (reserved)	
\$D5	( 213 )			Restore Default Turbo Mode	
\$D6	( 214 )			Set Centering YJK Modes/R25 Mask OFF (default)	
\$D7	( 215 )			Set Centering YJK Modes/R25 Mask ON	
\$F8	( 248 )			Reserve OCM-BIOS Reloading (cold reset or warm reset to go)	
\$F9	( 249 )			Reserve Slot-0 Primary Mode (warm reset to go) (internal OPLL disabled)	
\$FA	( 250 )			Reserve System Logo ON (warm reset only)	
\$FB	( 251 )			Cold Reset	
\$FC	( 252 )			Warm Reset w/ Mapper 2048kB (RAM size 6144kB if Extra-Mapper is ON)	
\$FD	( 253 )			Warm Reset	
\$FE	( 254 )			Warm Reset w/ Mapper 4096kB (RAM size 8192kB if Extra-Mapper is ON)	
\$FF	( 255 )			Restore All Default + Reserve Default Mapper & MegaSD	
More info on Switched I/O ports at MSX Assembly Page! < <a href="http://map.grauw.nl/resources/msx_io_ports.php#switch_io">http://map.grauw.nl/resources/msx_io_ports.php#switch_io</a> >					
R/W Logic	Positive	0 = OFF 1 = ON	( read / write )		
	Negative	0 = ON 1 = OFF	( read_n / write_n )		
Toggles	CPU Clock	[F12] or [DIP-SW1]			
	Video Output	[(SHIFT+)]PR[TRSC]R or [DIP-SW2/3]			
	Audio Mixer & SCRLK	[(SHIFT+)]PGUP/P[GDOWN]/F9/F10/F11] & [SCRLK]			SCRLK key could handle CMT or OPL3 depending on the type of machine
	Cartridge Slot-1	[SHIFT+F12] or [DIP-SW4]			
	Cartridge Slot-2	[SHIFT+SCRLK] or [DIP-SW5/6]			
	System Reset	[HARD RESET KEY] Fast or Long-Click (normal or full reboot)			
	Internal Mapper	[DIP-SW7] only			
Internal MegaSD	[DIP-SW8] only				